



3208 Park Center Drive • Tyler, TX 75701

Orders: (800) 648-7278 • Local: (903) 581-1855 • Fax: (903) 581-8206 • Customer Service: (903) 581-2417

Orciari Tachometer & Speed Trim Install Instructions

Part Numbers: 161306 & 161314

ATTENTION! READ THIS FIRST!

Parts that have been drilled, painted, altered, or installed are not returnable. This product is easy to moderate to install. However since each persons mechanical ability does vary, please read these instructions completely prior to starting the project. This part requires professional painting. If you have any doubt in your ability, we recommend having this work performed by a professional mechanic.

Parts Required:

- 1 Tachometer Trim
- 1 Speedo Trim

Tools Required:

- 1 Clear Silicone
- 1 Painter's Masking Tape

Technical Service

For any technical advice concerning this product or its' installation, call our Technical Support Line at (903) 581-1371.



Figure 2



Figure 3



Figure 1

Step 1: Prep and Paint

Have Trim pieces professional painted.

Step 2: Apply Silicone

Apply dime size amount of clear silicone adhesive to every other tab on the back side of the trim pieces as show in figure 1, 2 and 3.



Figure 4

Step 3: Install Tachometer Trim

Push tachometer trim over the outside of the factory tachometer making sure that the flat side of the trim is on the bottom. Wipe away any excess adhesive that may have pushed out.

Step 4: Tape Down

Use painter's masking tape to secure trim to tachometer overnight so adhesive has time to set. Read the instructions on the adhesive for the time it takes your adhesive to set.



Figure 5



Figure 6

Step 5: Install Speedo Trim

Push speedo trim over the outside of the factory speedo. The tabs at the top need to slide into the underside of the dash top. You may have to very lightly lift up the dash to help slide in tabs. Wipe away any excess adhesive that may have pushed out.

Step 4: Tape Down

Use painter's masking tape to secure trim to speedo overnight so adhesive has time to set. Read the instructions on the adhesive for the time it takes your adhesive to set.

COPYRIGHT

These instructions and photos are the property of BMP design / PROMINI and are not to be copied, duplicated or distributed for any purpose without written permission from BMP design / PROMINI.